



CUT LIST for HOW TO BUILD A WINDOW CORNICE

We made the frame of our cornice (not including the top and moldings) 38 inches wide by 6 1/8 inches deep by 7 1/4 inches tall to cover a 32-inch-wide window with a curtain rod that measures 35 inches from finial to finial and stands a maximum of 5 inches off the wall.

Cut List:

1x8 poplar front piece: one @ 38 inches from long point to long point

1x8 poplar sides: two @ 6 1/8 inches

1x4 poplar French cleat: one @ 36 1/2 inches

1x10 poplar top piece ripped to 8 1/2 inches: one @ 42 1/2 inches

3 5/8-inch primed-pine crown molding: Cut to fit.

3/4-inch primed pine ogee molding: Cut to fit.

Primed-pine cap molding: Cut to fit.